

Kombinieren Sie richtig! Bremscheiben & Bremsbeläge

Bremscheibe ► Bremsbelag ▼	ATE Serie	ATE Powerdisc	AP Serie	AP X-treme	Brembo Serie	Brembo Max	Brembo gelocht	Brembo geschlitzt	EBC Serie	EBC Turbo Groove	EBC Black Dash	Sandtler Typ S	Sandtler Typ RS/-A	Sandtler Typ GT/-A	Sandtler Typ N	Tarox Zero	Tarox G88	Tarox Sport Japan	Tarox F2000	Zimmermann Serie	Zimmermann gelocht	Zimmermann Formula Z
ATE Serie	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
ATE Power-Pad	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Carbone Lorraine RC5	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Carbone Lorraine RC6	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Carbone Lorraine RC8	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
EBC Black Stuff	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
EBC Green Stuff	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
EBC Red Stuff	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
EBC Yellow Stuff	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
EBC Blue Stuff	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Ferodo DS Performance	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Ferodo DS 2500	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Ferodo DS 3000	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Ferodo DS 4003	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Ferodo DS 1.11	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Ferodo DS 2.11	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Pagid RS4-2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Pagid RS4-4	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Pagid RS14	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Pagid RS15	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Pagid RS19/29	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

● unsere Empfehlung

● nur bedingt zu empfehlen

● nicht empfehlenswert